

Distribution of mean moving weekly inflows(MMWF)

T# = Total number of MMWF of Combined flow

S-77# = Total number of MMWF intervals at S-77RG

Run Name	2005BS		05LEC		05LORS		06LORS		07LORS	
MMWF CFS	T#	S-77#	T#	S-77#	T#	S-77#	T#	S-77#	T#	S-77#
>=4500	142	30	142	30	141	29	144	29	144	29

Total Combined Inflow = C-43 @ S-79

Formulas based on estuary.scr, a RECOVER PM.